

RFID Touch Password Cabinet lock SL-C114

User Manual



- There are two modes available for choosing in EM code locker lock: **Public Mode** and **Home Mode**.
- There are two unlocking methods for choosing: **single-unlocking method** and **double-unlocking method**

Part 1: EM Code Locker Lock in Public Mode

Lock in public mode has: 1 group of master password, 1 group of temporary password, 1 master card and 1 temporary card.

Password: 4~15 bits

I. **Default Status:**

Press the reset button on PCB for 5 times constantly, lock would turn into default status:
Master password: 12345678; Lock in Home mode, Single unlocking method.

II. **Swift Lock mode from Home mode to Public mode:**

Master Password + Key button + 7 + Key button: Lock is shift into Public mode and in Keep-open state.

III. **Operations:**

- A. Master card and Master password setting:** (Lock in Keep-open state and in Locked-state both workable)
1. Adding Master card:
When lock in Default status, the first card read by the lock reader is the master card.
 2. Changing Master Password:
Original master password + Key button + 1 + New Master password + Key button + Confirming new master password + Key button
- B. Adding temporary Password and card:**
1. Adding temporary password (when lock with single-unlocking method)
New Password + Key button + confirming new password + Key button: After this operation, lock would be closed.
 2. Adding temporary card (when lock with single-unlocking method)
Take any EM4100 card to be ready by the lock sensor: After this operation, lock would be closed.
 3. Adding temporary password and card (when lock with double-unlocking method)
 - 3.1 New password + Key button + confirming new password + Key button, then swipe an EM card: After these operations, lock would be closed.
 - 3.2 Swipe an EM card, then put in new password + Key button + confirming the new password + Key button: After these operations, lock would be closed.These two ways are both for adding temporary password and card to open lock together.
- C. Lock setting:**
1. Shifting between Home mode and Public mode:
Master password + key button + 7 + key button
 2. Shifting from Single-unlocking method to Double-unlocking method:
Master password + key button + 6 + key button
 3. Shifting from Double-unlocking method to Single-unlocking method:
Master password + key button + 5 + key button
- D. Unlocking:**
1. With single-unlocking method:
Temporary password(or master password) + Key button: Lock changed into keep-open state, temporary password and temporary card both become invalid.
 2. With Double-unlocking method:
 - 2.1 Master password + Key button; or swipe the master card : Lock changed into keep-open state, temporary password and temporary card both become invalid.
 - 2.2 Temporary password + Key button + swipe temporary card: Lock changed into keep-open state, temporary password and temporary card both become invalid.
 - 2.2 Swipe temporary Card + Put in Temporary Password + Press key button: Lock changed into keep-open state, temporary password and temporary card both become invalid.

Part 2: EM Code Locker Lock in Home Mode

Lock in public mode has: 1 group of master password, 200 groups of unlocking password

(numbered from 001 to 200), 1 master card and 200 unlocking cards (numbered from 001 to 200)

Password: 4~15 bits

I. Default Status:

Press the reset button on PCB for 5 times constantly, lock would turn into default status:

Master password: 12345678; Lock in Home mode, with Single-unlocking method.

II. Swift Lock mode from Public mode to Home mode:

Master Password + Key button + 7 + Key button: Lock is shifted into Home mode and in locked state.

III. Operations:

A. Master card and Master password setting:

1. Adding Master card:

When lock in Default status, the first card read by the lock reader is the master card.

2. Changing Master Password:

Original master password + Key button + 1 + New Master password + Key button +
Confirming new master password + Key button

B. Adding unlocking password and unlocking card:

1. Adding unlocking password:

Master password + Key button + 8 + number(001~200) + key button + unlocking
password+ Key button + Confirming unlocking password + Key button
(Unlocking passwords could be added continuously)

2. Adding unlocking card:

Swipe master card on lock sensor for twice, then Swipe the card you want to set as
unlocking card.

(Unlocking cards could be added continuously)

C. Deleting unlocking cards and password:

1. Deleting unlocking password:

Master password + Key button + 4 + number of the unlocking password (001~200)
+ Key button + confirming number(001~200) + key button: Passwords could be
deleted continuously.

2. Deleting unlocking card:

Swipe the master card for twice + press button 4 + number of that unlocking card
(001~200) + Key button + confirming number (001~200) + Key button: Unlocking
cards could be deleted continuously.

3. Deleting all of the unlocking passwords:

Master password + key button + 0 + key button

4. Deleting all of the unlocking password:

Swipe master card for twice + press 0 button + key button

D. Lock setting:

1. Shifting between Home mode and Public mode:

Master password + key button + 7 + key button

2. Shifting from Single-unlocking method to Double-unlocking method:
Master password + key button + 6 + key button
3. Shifting from Double-unlocking method to Single-unlocking method:
Master password + key button + 5 + key button

E. Unlocking:

1. With Single-unlocking method:
 - 1.1 Swipe any unlocking card or master card: Lock could be opened and then locked automatically after 5 seconds.
 - 1.2 Put in any group of unlocking password or master password: Lock could be opened and then locked automatically after 5 seconds.
 - 1.3 During the 5 seconds when the lock is open (when lock bolt is in the lock body), you could change the unlocking password:
Press 1 button + new unlocking password + Key button + confirming the new password + Key button
2. With Double-unlocking method:
 - 2.1 Master password + Key button; or swipe the master card : Lock could be opened and then locked automatically after 5 seconds.
 - 2.2 Unlocking password + Key button + swipe unlocking card: Lock could be opened and then locked automatically after 5 seconds.
 - 2.2 Swipe unlocking Card + Put in unlocking Password + Press key button: Lock could be opened and then locked automatically after 5 seconds.

Note: when lock is with double-locking method, password cannot be changed during the 5 seconds when the lock is open.
3. Putting wrong passwords constantly for 7 times would make the keypad locked for 2 minutes.

Other Functions:

1. If password is invalid, there would be three short sound of beep and blue light would be off.
2. If batteries in low power, there would low-voltage alarming; When the lock in very low voltage, unlocking cards cannot work and only the master card workable.

Special Tips:

1. For your property security, we strongly suggest you change the master password and deleting all unlocking password when lock installation finished.
2. For improving security, our lock could be unlocked by anti-peep password. For example: if your correct password is **123456**, you could add any numbers before or after this correct password (as long as the password you put in is no more than 32 bits), such as **02123456987**.

Main Function:

Card type: EM4100 ID card
Touchable keypad for password inputting
Micro-wave to check approaching card

Unlocking methods could be set by users: single-unlocking method or double-unlocking methods

Cards are set on lock without software: 1 master card and 200 unlocking cards at most.

Passwords could be changed by users: 1 master password and 200 unlocking password at most

Anti-peep password available, 32 bits at most.

Batteries power supply, external power supply in emergency.

Main Technical Data

Working Voltage: 6.0V (4 pieces of 1.5V alkaline batteries)

Static power consumption: <40uA

Dynamic power: <300 mA

Low voltage indication: <4.8V

Reading Card Distance: > 20mm

Temperature: 0°C -70°C

Working humidity: ≤ 80%